



Low Level Warning Panel

RCALM1
RCALM1L
RCALM1Q
RCALM1LQ
RCALM1B
RCALM1LB
RCALM1QB
RCALM1LQB

Installation and Operation Manual

Table of Contents

Description Of Operation.....	2
Models.....	2
Installation.....	3
Safety Precautions.....	3
Included Components.....	3
Layout.....	3
Control Panel Mounting.....	3
Wiring.....	4
RCALM1/RCALM1Q.....	4
RCALM1L/RCALM1LQ.....	6
RCALM1B/RCALM1QB.....	8
RCALM1LB/RCALM1LQB.....	11
Operation.....	13
Safety Precautions.....	13
Usage.....	13
Specifications.....	13

Description Of Operation

The RCALM1 Display Panel provides a basic highly visible level warning display for water tanks.

The amber low level warning light alerts the user to a low tank level and is accompanied by a repeating buzzer and volt-free BMS output (both optional) for audible alert. Float switch wiring can be reversed if required to provide a high level warning instead.

Models

RCALM1	Light, Buzzer, BMS, 230vac float switch
RCALM1L	Light, Buzzer, BMS, 24vdc float switch
RCALM1Q	Light, BMS, 230vac float switch
RCALM1LQ	Light, BMS, 24vdc float switch
RCALM1B	Light, Buzzer, 230vac float switch
RCALM1LB	Light, Buzzer, 24vdc float switch
RCALM1QB	Light, 230vac float switch

Installation

Safety Precautions

Mains Voltage – There are exposed electrical conductors inside this appliance. This appliance must be installed and serviced by a competent electrical technician to the current requirements of BS7671 and IEEE recommendations. Before servicing this appliance, normal safe isolation procedures should be implemented.

Do not touch any connection terminals while energised.

Do not attempt to service this item when wet, or in a wet or high humidity environment.

If the housing of the control panel becomes damaged, you must shut down and securely isolate this appliance immediately.

Included Components

RCALM1 Control Panel
Attached mains cable
Installation & Operation Manual

Float switch or level switch.

Layout

The control panel cannot be mounted outside, it is not fully weather resistant, but can be installed in sheltered outdoor locations (barns, covered areas, etc).


Suitable circuit protection must be installed and should include as a minimum a suitable earth, overcurrent protection, and residual current protection at 30mA, ideally on it's own circuit, but always in accordance with BS7671 and applicable regulations.

Control Panel Mounting

Open the cover of the control panel. There are 4 recesses, one on each corner of the panel. Drill through at these locations and attach to the wall or a suitable support, taking care not to damage cabling inside the panel. Fixings are not included and should be selected to suit the material to which the panel will be mounted.


Wiring

RCALM1/RCALM1Q



The control panel is supplied with wiring installed in the drawing shown above. The float or level switch needs to be fitted as shown in the next diagram.


Connections



Note that both wires to the float switch or level switch are live.


Note the green/yellow earth connection is provided for circuit protection to the appliance and has no function within the display panel which is Class 2 rated.

RCALM1L/RCALM1LQ



The control panel is supplied with wiring installed in the drawing shown above. The float or level switch needs to be fitted as shown in the next diagram.


Connections




Note that both wires to the float switch or level switch are live.

Note the green/yellow earth connection is provided for circuit protection to the appliance and has no function within the display panel which is Class 2 rated.

BMS Connection




RCALM1B/RCALM1QB



The control panel is supplied with wiring installed in the drawing shown above. The float or level switch needs to be fitted as shown in the next diagram.


Connections



Note that both wires to the float switch or level switch are live.


Note the green/yellow earth connection is provided for circuit protection to the appliance and has no function within the display panel which is Class 2 rated.

RCALM1LB/RCALM1LQB



The control panel is supplied with wiring installed in the drawing shown above. The float or level switch needs to be fitted as shown in the next diagram.

Connections



Note that both wires to the float switch or level switch are live.

Note the green/yellow earth connection is provided for circuit protection to the appliance and has no function within the display panel which is Class 2 rated.

Operation

Safety Precautions

Mains Voltage – There are exposed electrical conductors inside this appliance. Before servicing this appliance, normal safe isolation procedures should be implemented.

Do not attempt to operate this item when wet, or in a wet or high humidity environment.

If the housing of the control panel or attached wiring becomes damaged, you must shut down and securely isolate this appliance immediately.

Usage

The amber light shows that the tank is at a low level, as indicated by the installed position of the float switch or level switch.

Specifications

Dimensions	180mm x 110mm x 90mm
Enclosure Material	Polystyrene
Ingress Protection	IP66
Electrical Protection	Class 2
Voltage	230VAC 1~