

Parts list

For the following pumps:

XAJE80P

XAJE100P

XAJE120P

XJE80P

XJE100P

XJE120P

XJE120PT

XAJE80B

XAJE100B

XAJE120B

XJE80B

XJE100B

XJE120B

XJE120BT

To purchase any spare parts

please find the reference code

within this document then

search for that code on our

trade shop

<http://.steelpumps.mamutweb.com>

or call our technical service

 desk on **01239 623506**

during normal working hours.

REF.	DESCRIPTION	JE 80 B-P			JE 100 B-P			JE 120 B-P		
		CODE								
1	Electric Cable	01CEP001C								
2	Cable Gland	02OTP117G								
3	Washer	01VTP010C								
4	Cable Seal	02PLP188G								
5										
6	B-P type rear cap screw	02PLA560G								
7	Pressure Switch (O-ring included)	01PRP600C								
8	Electronic Card (Pressure gauge cable included)	04SPP956G								
9	Flow sensor (cable and connector included)	02PLA023L								
10	Flow sensor O-ring	01OGP001C								
11	Flow sensor Screw	01VTP033C								
12	Capacitor	01COP016C	01COP016C	01COP018C						
13	Electronic upper cap	02PLP202G								
14	Flow Indicator Impeller	02PLP206G								
15	Seeger	01VTP006C								
16	Electronic lower shelter	02PLP201G								
17	Flange O-ring	01OGP008C								
18	Chromium-plated brass Plug	02OTP120G								
19	Gasket Plug	01OGP035C								
20	2 holes Inox Handle	02IXP123G								
21	Front foot with holes (support)	02IXP017G								
22	Inox body screw	01VTP002C								
23	Inox Body-flange typeP screw (handle)	01VTP030C								
24	Nut M5	01VTP004C								
25	Pump body type P	02PLA524G								
26	Mechanical Seal	01TMP001C								
27	Inox body O-ring	01OGP164C								
	Type P body O-ring	01OGP164C								
28	Noryl Diffuser	02PLA020G								
29	Noryl Impeller	02PLP043G	02PLP044G	02PLP045G						
30	O-ring Venturi-pump body	01OGP010C								
31	Noryl Venturi	02PLP139G								
32	O-ring Venturi-diffuser	01OGP009C								
33	Inox pump Body	02IXA003L								
34	Holding board screw	01VTP005C								
35	Rotor shaft	02IXA550L	02IXA102L	02IXA022L						
	Front bearing	01CUP6203C								
	Rear bearing	01CUP6202C								
36	Inox 304 Sleeve and stator									
	Inox 304 Inner Sleeve	02IXP531G	02IXP007G							
	Stator	03SAA060L	03SAA070L	03SAA080L						
37	Stator sleeve O-ring	01OGP005C								
38	Inox 304 External Sleeve	02IXA540L	02IXA057L							
39	Techno-polymer Front flange	02PLP521G								
	Bearing housing	02ALP520L								
40	Techno-polymer rear flange	02PLP522G								
	Bearing housing	02ALP523L								
	Compensating ring	01VTP011C								
41	Washer	01VTP020C								
42	Stud	01VTP046C	01VTP045C							
43	B-P type rear cap screw	99VTP140C								
44	Body-flange screw type P	01VTP021C								

